

# ±30 Gauss, Monolithic, High Performance, 3-axis Magnetic Sensor with FIFO

# **MMC5617WA**


#### **FEATURES**

- Monolithic integrated 3-axis AMR magnetic sensor and electronic circuits requiring fewer external components
- Superior Dynamic Range and Accuracy:

  - ✓ ±30 G FSR✓ 20bits operation mode
  - √ 16bits resolution with FIFO
  - √ 0.0625 mG per LSB resolution
  - ✓ 2 mG total RMS noise
  - Enables heading accuracy of ±1°
- Sensor true frequency response up to 1KHz
- Ultra-Small Wafer Level Package 0.79x0.81x0.41 mm
- On-chip automatic degaussing with built-in **SET/RESET function** 
  - Eliminates thermal variation induced offset error (Null field output)
  - ✓ Clears the residual magnetization resulting from strong external fields
- On-chip sensitivity compensation
- On-chip temperature sensor
- Selftest signal available
- Low power consumption
- 1 µA power down current
- I<sup>2</sup>C slave, FAST (≤400 KHz) mode
- 1.2V to 3.6V compatible I2C interface
- RoHS compliant

### **APPLICATIONS**

- Electronic Compass & GPS Navigation
- Position Sensing



**FUNCTIONAL BLOCK DIAGRAM** 

### **DESCRIPTION**

The MMC5617WA is a monolithic complete 3-axis AMR magnetic sensor with on-chip signal processing and integrated digital bus (I2C fast mode), the device can be connected directly to a microprocessor, eliminating the need for A/D converters or timing resources.

It can measure magnetic fields within the full scale range of ±30 Gauss (G), with up to 0.0625mG per LSB resolution at 20bits operation mode and 2mG total RMS noise level, enabling heading accuracy of  $\pm 1^{\circ}$  in electronic compass applications. Contact MEMSIC for access to advanced calibration and tilt-compensation algorithms.

An integrated SET/RESET function provides for the elimination of error due to Null Field output change with temperature. In addition, it clears the sensors of any residual magnetic polarization resulting from exposure to strong external magnets. The SET/RESET function can be performed for each measurement or periodically as the specific application requires.

The MMC5617WA is in wafer level package with an ultra-small size of 0.79 x 0.81 x 0.41mm and with an operating temperature range from -40 °C to +85 °C.

Information furnished by MEMSIC is believed to be accurate and reliable. However, no responsibility is assumed by MEMSIC for its use, or for any infringements of patents or other rights of third parties which may result from its use. No license is granted by implication or otherwise under any patent or patent rights of MEMSIC.

**©MEMSIC**, Inc. www.memsic.com

# **SPECIFICATIONS** (Measurements @ 25 °C, unless otherwise noted; V<sub>DD</sub>= 1.8 V, Auto\_SR\_en=1, unless otherwise specified)


Parameter	Conditions	Min	Тур	Max	Units
Field Range (Each Axis) <sup>1</sup>	Total applied field		±30		G
Supply Voltage (V <sub>DD</sub> )		1.7	1.8	3.6	V
Interface(I2C) Voltage (V <sub>IO</sub> ) <sup>9</sup>		1.1	1.8	$V_{DD}$	V
Supply Voltage rise time				10.0	ms
11 7	BW=00		3.4		mA
Supply Current <sup>2,3</sup>	BW=01		2.4		mA
(100 measurements/second)	BW=10		1.3		mA
	BW=11		0.75		mA
Power Down Current <sup>3</sup>			1		μA
Operating Temperature		-40		85	°C
Storage Temperature		-55		125	°C
Linearity Error <sup>3</sup>	FS=±30 G				
(Best fit straight line)	H <sub>applied</sub> =±15 G		0.5	0.75	%FS
Hysteresis <sup>3</sup>	3 sweeps across ±30 G		0.02	0.1	%FS
Repeatability Error <sup>3</sup>	3 sweeps across ±30 G		0.02	0.1	%FS
Alignment Error			±1.0	±3.0	Degrees
Transverse Sensitivity <sup>3</sup>			±2.0		%
Transverse Constitution	BW=00		1.5	2.5	mG
_	BW=01		2.0	4.0	mG
Total RMS Noise <sup>3</sup>	BW=10		3.0	5.0	mG
	BW=11		4.0	7.0	mG
Output resolution	511-11		16	7.0	Bits
	BW=00	75	10		Hz
	BW=01	125			Hz
Max Output data rate <sup>4</sup>	BW=10	255			Hz
	BW=11	255		800	Hz
Heading accuracy <sup>3,5</sup>			±1.0	±3.0	Degrees
. rousing accuracy	±30 G <sup>8</sup>	-5		5	%
Sensitivity <sup>6</sup>	With16bits operation <sup>3</sup>	Ů	1024	Ŭ	counts/G
Conditivity	With18bits operation		4096		counts/G
	With 20bits operation		16384		counts/G
Sensitivity Change Over	-40~+85 °C		10001		
Temperature <sup>3</sup>	Delta from 25 °C			±5	%
Tomporatoro	Delta Hom 25 C	-1.0		1.0	G
	With16bits operation	1.0	32768	1.0	Counts
Null Field Output <sup>8</sup>	With18bits operation		131072		Counts
	With 20bits operation		524288		Counts
Null Field Output Change Over	With 20010 operation				
Temperature <sup>3</sup>			±0.2	±1.0	mG/°C
Temperature Sensor Output <sup>3</sup>	+	0.6	0.8	1.0	°C/Count
Disturbing Field <sup>7</sup>		32	0.0	1.0	G
Maximum Exposed Field		32		10,000	G
Output Repeatability <sup>3</sup>			2.0	10,000	mG
Output Repeatability		<u> </u>	∠.∪	<u> </u>	I IIIG

#### Notes:

- 1. External magnetic field on each axis not continuously higher than 16G.
- Supply current is proportional to how many measurements performed per second, 50Hz for BW=00.
- 3. Based on 3lots characterization result.
- 4. The 800 Hz ODR is available by writing 255 into Register ODR , setting hpower to 1, en\_odr2k = 1
- 5. MEMSIC product enables users to utilize heading accuracy to be 1.0 degree typical when using MEMSIC's proprietary software or algorithm.
- 6. Sensitivity of the orthogonal axes is analytically derived from raw data and is subsequently processed by MEMSIC software drivers.
- 7. This is the magnitude of external field that can be tolerated without changing the sensor characteristics. If the disturbing field is exceeded, a SET/RESET operation is required to restore proper sensor operation.
- 8. Based on shipment test result.
- A dedicated block automatically samples the high voltage of the bus interface (sda and scl), averages the sampled high voltage in time domain and holds
  this average voltage as V<sub>IO</sub>

# I<sup>2</sup>C INTERFACE I/O CHARACTERISTICS


Parameter	Symbol	Test Condition	Min.	Тур.	Max.	Unit
Logic Input Low Level	V <sub>IL</sub>		-0.5		0.3* V <sub>IO</sub>	V
Logic Input High Level	VIH		0.7*V <sub>IO</sub>		Vio	V
Hysteresis of Schmitt input	V <sub>hys</sub>		0.2			V
Logic Output Low Level	VoL				0.4	V
Input Leakage Current	li	0.1V <sub>IO</sub> <v<sub>in&lt;0.9V<sub>IO</sub></v<sub>	-10		10	μA
SCL Clock Frequency	fscL		0		400	kHz
START Hold Time	t <sub>HD;STA</sub>		0.6			μS
START Setup Time	tsu;sta		0.6			μS
LOW period of SCL	tLOW		1.3			μS
HIGH period of SCL	thigh		0.6			μS
Data Hold Time	t <sub>HD;DAT</sub>		0		0.9	μS
Data Setup Time	tsu;dat		0.1			μS
Rise Time	t <sub>r</sub>	From V <sub>IL</sub> to V <sub>IH</sub>			0.3	μS
Fall Time	t <sub>f</sub>	From V <sub>IH</sub> to V <sub>IL</sub>			0.3	μS
Bus Free Time Between STOP and START	tBUF		1.3			μS
STOP Setup Time	tsu;sto		0.6			μS



# **POWER ON SEQUENCE**

(Measurements @ 25  $^{\circ}$ C, unless otherwise noted;  $V_{DD}$ = 1.8 V, unless otherwise specified)

Parameter	Symbol	Min.	Тур.	Max.	Unit
Supply Voltage Rise Time	Tvr	1e-3		10	ms
Time to operate device after V <sub>DD</sub> valid	Тор	5			ms
Time sequence between VDD and V <sub>IO</sub> *	Tio	0			us



#### ABSOLUTE MAXIMUM RATINGS\*

Supply Voltage -0.5 to +5 V Storage Temperature -55 °C to +125 °C Maximum Exposed Field 10000 G

**Note:** Stresses above those listed under Absolute Maximum Ratings may cause permanent damage to the device. This is a stress rating only; the functional operation of the device at these or any other conditions above those indicated in the operational sections of this specification is not implied. Exposure to absolute maximum rating conditions for extended periods may affect the device's reliability.

### Pin Description: WLP Package

Pin	Name	Description	I/O
A1	VSA	Connect to Ground	Р
A2	SCL	Serial Clock Line	I
B1	VDD	Power Supply	Р
B2	SDA	Serial Data Line	I/O


All parts are shipped in tape and reel packaging with 10000pcs (or 5000pcs per requested) per 7" reel.

### Caution:

This is an Electro-static Discharge (ESD) sensitive device.

### **Ordering Guide:**


MMC5617WA (I2C 7bits Device Addr: 0x30)



Package type:

Code	Туре
W	WLP package RoHS compliant

### MARKING ILLUSTRATION



**Note:** "Number" (top-left character) is used to differentiate between similar devices. The black dot marks the location of pin one (1). The 2<sup>nd</sup> line represents the device's Lot Number.


### THEORY OF OPERATION

The Anisotropic Magneto-Resistive (AMR) sensors are special resistors made of permalloy thin film deposited on a silicon wafer. During manufacturing, a strong magnetic field is applied to the film to orient its magnetic domains in the same direction, establishing a magnetization vector. Subsequently, an external magnetic field applied perpendicularly to the sides of the film causes the magnetization to rotate and change angle. This effect causes the film's resistance to vary with the intensity of the applied magnetic field. The MEMSIC AMR sensor is incorporated into a Wheatstone bridge configuration to maximize Signal to Noise ratio. A change in magnetic field produces a proportional change in differential voltage across the Wheatstone bridge

However, the influence of a strong magnetic field (more than 30 G) in any direction could upset, or flip, the polarity of the film, thus changing the sensor characteristics. A strong restoring magnetic field must be applied momentarily to restore, or set, the sensor characteristics. The MEMSIC magnetic sensor has an on-chip magnetically coupled strap: a SET/RESET strap pulsed with a high current, to provide the restoring magnetic field.

### **EXTERNAL CIRCUITRY CONNECTION**

The MMC5617WA can operate from a single 1.7V to 3.6V supply. The circuit connection diagrams below illustrate power supply connection options.



<Top View>

### **Connection Block Diagram**

### PIN DESCRIPTIONS

**VDD** – This is the power supply pin. MEMSIC recommends a minimum bypass capacitor of 2.2  $\mu$ F placed in close proximity to the VDD pin.

VSA - This is the ground pin for the magnetic sensor.

**SDA** – This pin is the I<sup>2</sup>C serial data line.

**SCL**– This pin is the I<sup>2</sup>C serial clock line.

### HARDWARE DESIGN CONSIDERATION

- ✓ Provide adequate separation distance to devices that contain permanent magnets or generate magnetic fields (e.g. speakers, coils, inductors) The combined magnetic field to be measured and interference magnetic field should be less than the full scale range of the MMC5617WA (±30 G).
- ✓ Provide adequate separation distance to current carrying traces. Do not route current carrying traces under the sensor or on the other side of the PCB opposite the device.
- ✓ Do not cover the sensor with magnetized material or material that may become magnetized, (e.g., shield box, LCD, battery, iron bearing material).
- ✓ Do not place the device opposite magnetized material or material that may become magnetized located on the other side of the PCB.

Details please refer to MEMSIC Magnetic Sensor Hardware Design Layout Guideline for Electronic Device.


### **POWER CONSUMPTION**

The power consumed by the device is proportional to the number of measurements taken per second. For example, when BW<1:0>=10, MMC5617WA consumes 1.3mA (typical) at 1.8V with 100 measurements per second. If only 1 measurement are performed per second, the current will be  $1300*1/100=13\mu A$ .

### I<sup>2</sup>C INTERFACE DESCRIPTION

The I<sup>2</sup>C (or Inter IC bus) is an industry standard bi-directional two-wire interface bus. A master I<sup>2</sup>C device can operate READ/WRITE controls to 128 devices by device addressing. The MEMSIC magnetic sensor operates only in a slave mode, i.e. only responding to calls by a master device.

### I<sup>2</sup>C BUS CHARACTERISTICS



The two wires in the I<sup>2</sup>C bus are called SDA (serial data line) and SCL (serial clock line). In order for a data transfer to start, the bus has to be free, which is defined by both wires in a HIGH output state. Due to the open-drain/pull-up resistor structure and wired Boolean "AND" operation, any device on the bus can pull lines low and overwrite a HIGH signal. The data on the SDA line has to be stable during the HIGH period of the SCL line. In other words, valid data can only change when the SCL line is LOW.

Note: Rp selection guide: 2.7Kohm for a short I<sup>2</sup>C bus length (less than 10 cm), and 10Kohm for a bus length less than 5 cm.

# **REGISTER MAP**

Register Name	Address (HEX)	Description
Xout0	00H	Xout[19:12]
Xout1	01H	Xout[11:4]
Yout0	02H	Yout[19:12]
Yout1	03H	Yout[11:4]
Zout0	04H	Zout[19:12]
Zout1	05H	Zout[11:4]
XYout2	06H	Xout[3:0], Yout[3:0]
Zout2	07H	Zout[3:0]
Fifo_Status	08H	Current Sample count in FIFO
Tout	09H	Temperature output
Fifo control	0EH	FIFO control
Status1	18H	Device status1
Status0	19H	Device status0
ODR	1AH	Output Data Rate
Internal control 0	1BH	Control register 0
Internal control 1	1CH	Control register 1
Internal control 2	1DH	Control register 2
ST_X_TH	1EH	X-axis selftest threshold
ST_Y_TH	1FH	Y-axis selftest threshold
ST_Z_TH	20H	Z-axis selftest threshold
Ana control	22H	Analog addr
ST_X	27H	X-axis selftest set value
ST_Y	28H	Y-axis selftest set value
ST_Z	29H	Z-axis selftest set value
Product ID	39H	Product ID

# **REGISTER DETAILS**

Xout0, Xout1, Xout2

Noute, Adutt, Ad	_		_				1 .	
Xout0	7	6	5	4	3	2	1	0
Addr: 00H				Xout[1	9:12]			
Mode		Read-only						
Xout1	7	6	5	4	3	2	1	0
Addr: 01H		Xout[11:4]						
Mode	Read-only							
V/V10	7	0			_	0	1 4	1 0

X/Yout2	7	6	5	4	3	2	1	0
Addr: 06H	Xout[3:0]				Yout[3:0]			
Mode		Read-only						

X-axis output, unsigned format.

X-axis output	Data
16bits operation mode	Xout[19:4]
18bits operation mode	Xout[19:2]
20bits operation mode	Xout[19:0]

Yout0, Yout1, Yout2

,,								
Yout0	7	6	5	4	3	2	1	0
Addr: 02H		Yout[19:12]						
Mode		•		Read-o	only		•	

Yout1	7	6	5	4	3	2	1	0
Addr: 03H	Yout[11:4]							
Mode		Read-only						

Y-axis output, unsigned format.

Y-axis output	Data
16bits operation mode	Yout[19:4]
18bits operation mode	Yout[19:2]
20bits operation mode	Yout[19:0]

# Zout0, Zout1, Zout2

Zout0	7	6	5	4	3	2	1	0			
Addr: 04H		Zout[19:12]									
Mode		Read-only									
					-						
Zout1	7	6	5	4	3	2	1	0			
Addr: 05H				Zout	11:4]						
Mode		Read-only									
Zout2	7	6	5	4	3	2	1	0			
Addr: 07H		Zout[3:0]				0	0	0			

Read-only

Z-axis output, unsigned format.

Mode

Z-axis output	Data
16bits operation mode	Zout[19:4]
18bits operation mode	Zout[19:2]
20bits operation mode	Zout[19:0]

Fifo_Status	7	6	5	4	3	2	1	0
Addr: 08H	0	Fifo_int	Fifo_empty	Fifo_full	fifo_usage[3:0]			
Mode	Read-only							

Bit Name	Description
Fifo_int	Interrupt when the fifo reaches wm or is full
Fifo_empty	fifo full indicator, 1'b1 means fifo is full
Fifo_full	fifo empty indicator, 1'b1 means fifo is empty
Fifo_usage[3:0]	fifo usage bits, fifo depth is 16. 4'b0000 means fifo is empty, 4'b1111 means that there are 15 sets of measurement data in fifo.

Z-axis output, unsigned format.

<u> </u>	
Z-axis output	Data
16bits operation mode	Zout[19:4]

### **Temperature Out**

Temperature	7	6	5		4	3	2	1	0	
Addr: 09H		Tout[7:0]								
Mode			Read-only							

Temperature output, unsigned format. The range is -75-125°C, about 0.8°C/LSB, 00000000 stands for -75°C

# **Fifo Control**

Fifo	7	6	5	4	3	2	1	0
control								
Addr:	Addr_loop_en	Fifo_wm[3]	Fifo_wm[2]	Fifo_wm[1]	Fifo_wm[0]	1'b0	Fifo_int_en	Fifo_en
0EH								
Reset	0	1	1	1	1	0	0	0
Value	U	-	l	I	I .	0	U	O
Mode	Read-only							

Bit Name	Description
Addr_loop_en	fifo address loopback enable, when this bit set to 1, address will loopback in address range 0h-5h (x0,x1,y0,y1,z0,z1).
Fifo_wm[3:0]	fifo watermark, interrupt will be raised up if usage is greater than watermark
Fifo_int_en	fifo interrupt enable, when enable, fifo will generate interrupt when watermark has been reached
Fifo_en1 <sup>1</sup>	fifo enable bit, fifo is bypassed when this bit set to 0. when this bit is set to 1'b1, 6tytes(xout0,xout1,yout0,yout1,zout0,zout1) should be read at a time

### Notes:

### Status1

Device Status1	7	6	5	4	3	2	1	0	
Addr: 18H	Meas_t_	Meas_m	Sat_se	OTP_read	ST Fail	Mdt_flag	Meas_t_d	Meas_m_	
Addi: 1011	done	_done	nsor	_done	O1_1 all	_int	one_int	done_int	
Reset Value	0	0	0	0	0	0	0	0	
Mode		Read-only							

Bit Name	Description
Meas_m_done_int	This bit indicates whether Take Measurement of Magnetic field command has been completed
wieas_m_done_int	and data ready to be read by the host.
Moos t done int	This bit indicates whether Take Measurement of Temperature command has been completed
Meas_t_done_int	and data ready to be read by the host.
	This bit indicates whether a motion is detected by the motion detector. This bit is set High
Mdt_flag_int	when a motion is detected, and it is reset when Start_MDT is received, or an IBI is sent to the
	master, or this bit is read.
ST_Fail	This bit is specifically for I3C IBI, and not available of this chip.
	This bit is an indicator of successfully reading its OTP memory either as part of its power up
OTP_read_done <sup>1</sup>	sequence, or after an I2C command that reloads the OTP memory, such as resetting the chip
	and refreshing the OTP registers.
Sat_sensor	This bit is an indicator of the selftest signal, it keeps low once the device PASS selftest.
Meas_m_done1	This bit indicates that a measurement of magnetic field is done and the data is ready to be
ivieas_m_done	read. This bit is reset only when any of the magnetic data registers is read.
Moos t dono1	This bit indicates that a measurement of temperature is done and the data is ready to be read.
Meas_t_done <sup>1</sup>	This bit is reset only when the temperature register is read.

# Status0

<sup>1.</sup> When fifo\_en and addr\_loop\_en are set to 1'b1, at most 16\*6bytes can be read at a time

Addr: 19H	Activity Mode[1:0]		Protocol error	0	0	Mar naa i		Interrupt er[1:0]
Reset Value	0	0	0	0	0	0	0	0
Mode		R						

Bit Name	Description				
	0b00 – no interrupts pending.				
Pending Interrupt	0b01 - either of the Meas_m_done_int or Meas_t_done_int is high				
Number[1:0]	0b10 - Mdt_flag_int bit is high				
	0b11 – protocol error is detected.				
Mdt flog	This bit becomes high when motion is detected. This bit is cleared when a new Start_MDT bit				
Mdt_flag	is written t 1.				
Protocol error	I3C Protocol error, and not available of this chip.				
Activity Mode[0]	Always 0				
Activity Mode[4]	0 – MMC5617WA is in power down mode.				
Activity Mode[1]	1 – MMC5617WA is actively performing a measurement				

# ODR

ODR	7	6	5	4	3	2	1	0
Addr: 1AH		ODR[7:0]						
Reset Value	0	0	0	0	0	0	0	0
Mode		Read/Write						

Bit Name	Descrip	Description							
	by either defining configura	This byte defines the frequency of the continuous-mode measurements. ODR can be defined by either writing the number into this register, or using SETXTIME CCC command, followed by defining byte of 0x8F. In order to enter the continuous mode, this byte should not be zero. The configurable ODR is 1 to 255, with increment of 1. The 1000 Hz or 1500 Hz ODR is available by writing 255 into this byte and setting hpower to 1. The maximum reachable ODR as below:							
ODR[7:0]	BW	Automatic SET/RESET	No SET/RESET						
	00	75Hz	150 Hz						
	01	125 Hz	255 Hz						
	10	255 Hz	255 Hz						
11 hpower=0: 255Hz; hpower=0: 255 Hz;									
	hpower=1 en_odr2k=0: 500 Hz; hpower=1 en_odr2k=0: 1000 Hz;								
	hpower=1 en_odr2k=1: 800 Hz hpower=1 en_odr2k=1: 1500 Hz								

# Internal Control 0

Control Register 0	7	6	5	4	3	2	1	0		
Addr: 1BH	Cmm_fre q_en	Auto_st_ en	Auto_SR _en	Do Reset	Do Set	Start_MD T	Take_me as_T	Take_me as_M		
Reset Value	0	0	0	0	0	0	0	0		
Mode		Read/Write								

Bit Name	Description
Take_meas_M¹	Take Measure of Magnetic field, or TM_M bit. Writing a 1 into this location causes the chip to perform a magnetic measurement. This bit is self-clearing at the end of each measurement.
Take_meas_T	Take Measure of Temperature, or TM_T bit. Writing a 1 into this location causes the chip to perform a temperature measurement. This bit is self-clearing at the end of each measurement.
Start_MDT	Factory use only, reset value is 0.
Do Set	Writing a 1 into this location will cause the chip to do the Set operation, which will allow large set current to flow through the sensor coils for 375ns. This bit is self-cleared at the end of Set operation.

Do Reset	Writing a 1 into this location will cause the chip to do the Reset operation, which will allow large reset current to flow through the sensor coils for 375ns. This bit is self-cleared at the end of Reset operation.
Auto_SR_en	Writing a 1 into this location will enable the function of automatic set/reset. This function applies to both on-demand and continuous-time measurements. This bit must be set to 1 in order to activate the feature of periodic set. This bit is recommended to set to "1" in the application.
Auto_st_en	Writing a 1 into this location will enable the function of automatic self-test. The threshold in register 1EH, 1FH, 20H should be set before this bit is set to 1. This bit clears itself after the operation is completed.
Cmm_freq_en	Writing a 1 into this location will start the calculation of the measurement period according to the ODR. This bit should be set before continuous-mode measurements are started.

# **Internal Control 1**

Control	7	6	5	4	3	2	1	0
Register 1								
Addr: 1CH	Sw_reset	St_enm	St_enp	Z-inhibit	Y-inhibit	X-inhibit	BW1	BW0
Reset Value	0	0	0	0	0	0	0	0
Mode	Read/Write							

Bit Name		Description								
	These bandwidth selection bits adjust the length of the decimation filter. They control the duration									
	of each measurement.									
	BW1	BW0	Measurement Time							
DIMO 8	0	0	6.6ms							
BW0 & BW1	0	1	3.5ms							
DVVI	1	0	2.0ms							
	1	1	1.2ms							
	Note: X/Y/Z channel measurements are taken sequentially. Delay Time among those									
	measurem	neasurements is 1/3 of the Measurement Time defined in the table.								
X-inhibit	Writing "1	Writing "1" will disable this channel, and reduce Measurement Time and total charge per								
Y-inhibit	measurem	ent. Wher	n a channel is disabled	I it is simply skipped during Take Measure routine. Its						
Z-inhibit	output register is not reset and will maintain the last value written to it when this channel was									
Z-IIIIIDIL	active. Note: Y/Z needs to be inhibited the same time in case needed.									
				current through the self-test coil of the sensor. This						
St_enp	current will cause an offset of the magnetic field. This function is used to check whether the									
	sensor has been saturated.									
St enm	The function	on of this	bit is similar to ST_EN	NP, but the offset of the magnetic field is of opposite						
Ot_emm	polarity.									
Sw_reset	Software I	Reset. Wr	iting "1" will cause th	e part to reset, similar to power-up. It will clear all						
OW_1696f	registers a	ınd also re	-read OTP as part of it	ts startup routine. The power on time is 20mS.						

# **Internal Control 2**

Control Register 2	7	6	5	4	3	2	1	0
Addr: 1DH	hpower	INT_meas _done_en	INT_mdt_ en	Cmm_en	En_prd_s et		Prd_set[2:0]	
Reset Value	0	0	0	0	0	0	0	0
Mode	Read/Write							

Bit Name	Description
Dud 4[0.0]	These bits determine how many measurements are done before a set is executed, when the
Prd_set[2:0]	part is in continuous mode and the automatic set/reset is enabled. From 000 to 111, the sensor will do one set for every 1, 25, 75, 100, 250, 500, 1000, and 2000 samples. In order to enable

	this feature, both En_prd_set and Auto_SR must be set to 1, and the part should work in continuous mode. Please note that during this operation, the sensor will not be reset.
En_prd_set	Writing 1 into this location will enable the function of periodical set.
Cmm_en	The device will enter continuous mode, if ODR has been set to a non-zero value and a 1 has been written into Cmm_freq_en. The internal counter will start counting as well since this bit is set.
INT_mdt_en	Factory use only, reset value is 0.
INT_meas_done_en	Factory use only, reset value is 0.
hpower	If this bit is set to 1 to achieve 1000Hz or 1500Hz ODR.

# ST\_X\_TH

ST_X_TH	7	6	5	4	3	2	1	0
Addr: 1EH		ST_X_TH[7:0]						
Reset Value	0	0	0	0	0	0	0	0
Mode		Write-only						

X-axis selftest threshold

# ST\_Y\_TH

ST_Y_TH	7	6	5	4	3	2	1	0
Addr: 1FH		ST_Y_TH[7:0]						
Reset Value	0	0 0 0 0 0 0 0						
Mode		Write-only						

Y-axis selftest threshold

# ST\_Z\_TH

ST_Z_TH	7	6	5	4	3	2	1	0
Addr: 20H		ST_Z_TH[7:0]						
Reset Value	0	0 0 0 0 0 0 0						
Mode		Write-only						

Z-axis selftest threshold

### **Ana Control**

Ana Control	7	6	5	4	3	2	1	0
Addr: 22H								En_odr2k
Reset Value	0	0	0	0	0	0	0	0
Mode	Read/Write							

Bit Name	Description
En_odr2k	set odr up to 1500Hz

# ST\_X

ST_X	7	6	5	4	3	2	1	0	
Addr: 27H		ST_X[7:0]							
Reset Value		Factory stored value							
Mode		Read/Write							

X-axis selftest set value

# ST\_Y

ST_Y	7	6	5	4	3	2	1	0
Addr: 28H				ST_Y	′[7:0]			

Reset Value	Factory stored value
Mode	Read/Write

Y-axis selftest set value

### ST Z

ST_Z	7	6	5	4	3	2	1	0
Addr: 29H		ST_Z[7:0]						
Reset Value		Factory stored value						
Mode		Read/Write						

Z-axis selftest set value

#### **Product ID 1**

Product ID 1	7	6	5	4	3	2	1	0
Addr: 39H		Product ID1[7:0]						
Reset Value	0	0 0 1 0 1 0						
Mode		Read-only						

Product ID, used to recognize device.

### I<sup>2</sup>C Interface operation:

### **DATA TRANSFER**

A data transfer is started with a "START" condition and ended with a "STOP" condition. A "START" condition is defined by a HIGH to LOW transition on the SDA line while SCL line is HIGH. A "STOP" condition is defined by a LOW to HIGH transition on the SDA line while the SCL line is held HIGH. All data transfer in I<sup>2</sup>C system are 8-bits long. Each byte has to be followed by an acknowledge bit. Each data transfer involves a total of 9 clock cycles. Data is transferred starting with the most significant bit (MSB).

After a START condition, the master device calls a specific slave device by sending its 7-bit address with the 8<sup>th</sup> bit (LSB) indicating that either a READ or WRITE operation will follow, [1] for READ and [0] for WRITE. The MEMSIC device 7-bit device address is [0110000] where the three LSB's are pre-programmed into the MMC5617WA by the factory.

Note: A total of 8 different addresses can be pre-programmed into MEMSIC device by the factory. This variation of I<sup>2</sup>C address avoids a potential address conflict, either by ICs from other manufacturers or by other MEMSIC devices on the same bus.

The initial addressing of the slave is always followed by the master writing the number of the slave register to be read or written, so this initial addressing always indicates a WRITE operation by sending **[01100000]**. After being addressed, the MEMSIC device being called should respond by an "Acknowledge" signal by pulling SDA line LOW. Subsequent communication bytes can either be

- a) The data to be written to the device register, or
- **b)** Another START condition followed by the device address indicating a READ operation **[01100001]**, and then the master reads the register data.

Multiple data bytes can be written or read to numerically sequential registers without the need of another START condition. Data transfer is terminated by a STOP condition or another START condition. Two detailed examples of communicating with the MEMSIC device are listed below for the actions of acquiring a magnetic field measurement and magnetizing the sensor.

#### **EXAMPLE OF MEASUREMENT**

1<sup>st</sup> cycle: A START condition is established by the Master Device followed by a call to the slave address [0110000] with the eighth bit held low to indicate a WRITE request.

**2<sup>nd</sup> cycle**: After an acknowledge signal is received by the master device (MEMSIC device pulls SDA line low during 9<sup>th</sup> SCL pulse), the master device sends the address of Control Register 0 as the target register to be written. The MEMSIC device should acknowledge receipt of the address (9<sup>th</sup> SCL pulse, SDA pulled low).

**3<sup>rd</sup> cycle**: The Master device writes to the Internal Control Register 0 the code [00100001] (TM\_M and Auto\_SR\_en high) to initiate data acquisition. The MEMSIC device should send an Acknowledge and internally initiate a measurement (collect x, y and z data). A STOP condition indicates the end of the write operation.

**4<sup>th</sup> cycle**: The Master device sends a START command followed by the MEMSIC device's seven bit address, and finally the eighth bit set low to indicate a WRITE. An Acknowledge should be send by the MEMSIC device in response.

5th cycle: The Master device sends the MEMSIC Device Status Register 1 as the address to read.

**6**<sup>th</sup> **cycle**: The Master device sends a START command followed by the MEMSIC device's seven bit address, and finally the eighth bit set high to indicate a

READ. An Acknowledge should be send by the MEMSIC device in response.

**7<sup>th</sup> cycle**: The Master device cycles the SCL line. This causes the Status Register data to appear on SDA line. Continuously read the Device Status Register1 until the Meas\_M\_Done bit (bit 1) is set to '1'. This indicates that data for the x, y, and z sensors is available to be read.

**8**<sup>th</sup> **cycle**: The Master device sends a START command followed by the MEMSIC device's seven bit address, and finally the eighth bit set low to indicate a WRITE. An Acknowledge should be send by the MEMSIC device in response.

9<sup>th</sup> cycle: The Master device sends a [00000000] (Xout LSB register address) as the register address to read.

**10**<sup>th</sup> **cycle**: The Master device calls the MEMSIC device's address with a READ (8<sup>th</sup> SCL cycle SDA line high). An Acknowledge should be send by the MEMSIC device in response.

**11**<sup>th</sup> **cycle**: Master device continues to cycle the SCL line, and each consecutive byte of data from the X, Y and Z registers should appear on the SDA line. The internal memory address pointer automatically moves to the next byte. The Master device acknowledges each. Thus:

```
12<sup>th</sup> cycle: Xout[19:12].
13<sup>th</sup> cycle: Xout[11:4].
14<sup>th</sup> cycle: Yout[19:12].
15<sup>th</sup> cycle: Yout[11:4].
16<sup>th</sup> cycle: Zout[19:12].
17<sup>th</sup> cycle: Zout[11:4].
18<sup>th</sup> cycle: Xout[3:2] for 18bits mode. Xout[3:0] for 20bits mode
19<sup>th</sup> cycle: Yout[3:2] for 18bits mode. Yout[3:0] for 20bits mode
20<sup>th</sup> cycle: Zout[3:2] for 18bits mode. Zout[3:0] for 20bits mode:0].
```

Master ends communications by NOT sending an 'Acknowledge' and also follows with a 'STOP' command.

#### **EXAMPLE OF CONTINUOUS MODE**

The MMC5617WA is designed with an on-chip continuous mode, or CMM. When enabled, the part will periodically take a measurement and store the results in I<sup>2</sup>C register. The frequency of these measurements is controlled by a setting in I<sup>2</sup>C register. The results of the last measurement can be read by the host. This mode, while it consumes more current, eliminates the need for the host to request measurements every time.

First the user needs to write the desired number into ODR[7:0]. It should be a non-zero integer, otherwise the continuous mode will not be activated. Then Cmm\_freq\_en is set to 1 to let the internal circuitry to calculate the target number for the counter. After that Cmm\_en is set to 1 and the continuous mode is started and the internal counter starts to count at the same time.

#### **EXAMPLE OF RESET**

1st cycle: A START condition is established by the Master Device followed by a call to the slave address [0110000] with the eighth bit held low to indicate a WRITE request.

**2<sup>nd</sup> cycle**: After an acknowledge signal is received by the master device (The MEMSIC device pulls the SDA line low during the 9<sup>th</sup> SCL pulse), the master device sends [00011011] as the target address (Internal Control Register 0). The MEMSIC device should acknowledge receipt of the address (9<sup>th</sup> SCL pulse).

**3<sup>rd</sup> cycle**: The Master device writes to the MEMSIC device's Internal Control 0 register the code [00010000] (RESET bit) to initiate a RESET action. The MEMSIC device should send an Acknowledge.

At this point, the MEMSIC AMR sensors have been conditioned for optimum performance and data measurements can commence.

### **EXAMPLE OF SET**

1st cycle: A START condition is established by the Master Device followed by a call to the slave address [0110000] with the eighth bit held low to indicate a WRITE request.

**2<sup>nd</sup> cycle**: After an acknowledge signal is received by the master device (The MEMSIC device pulls the SDA line low during the 9<sup>th</sup> SCL pulse), the master device sends [00011011] as the target address (Internal Control Register 0). The MEMSIC device should acknowledge receipt of the address (9<sup>th</sup> SCL pulse).

**3<sup>rd</sup> cycle**: The Master device writes to the MEMSIC device's Internal Control 0 register the code [00001000] (SET bit) to initiate a SET action. The MEMSIC device should send an Acknowledge.

#### USING SET AND RESET TO REMOVE BRIDGE OFFSET

The integrated SET and RESET functions of the MMC5617WA enables the user to remove the error associated with bridge Offset change as a function of temperature, thereby enabling more precise heading measurements over a wider temperature than competitive technologies. The SET and RESET functions effectively alternately flip the magnetic sensing polarity of the sensing elements of the device.

- 1) The most accurate magnetic field measurements can be obtained by using the protocol described as follows: Perform SET. This sets the internal magnetization of the sensing resistors in the direction of the SET field.
- 2) Perform MEASUREMENT. This measurement will contain not only the sensors response to the external magnetic field, H, but also the Offset; in other words,

Output1 = +H + Offset.

- 3) Perform RESET. This resets the internal magnetization of the sensing resistors in the direction of the RESET field, which is opposite to the SET field (180° opposed).
- 4) Perform MEASUREMENT. This measurement will contain both the sensors response to the external field and also the Offset. In other words,

Output2 = -H + Offset.

5) Finally, calculate H by subtracting the two measurements and dividing by 2. This procedure effectively eliminates the Offset from the measurement and therefore any changes in the Offset over temperature.

H = (Output1-Ouput2)/2.

### Note:

• To calculate and store the offset; add the two measurements and divide by 2. This calculated offset value can be subtracted from subsequent measurements to obtain H directly from each measurement.

### **EXAMPLE OF SELFTEST**

The MMC5617WA is designed with an on-chip selftest signal to do self-diagnose of the sensor:

1) Read out the selftest signal stored at register 27H, 28H, and 29H.

- 2) Calculate the selftest signal threshold with 80% of the data readout from above registers.
- 3) Write the threshold in to the register 1EH, 1FH, and 20H.
- 4) Write [01000001] (TM M and auto st en high) to Internal Control Register 1BH to initiate a selftest.
- 5) Read out value of Sat\_sensor bit at the Device Status register 18H.
- 6) Sat sensor=0, PASS selftest.

#### **EXAMPLE OF PASSWORD**

1st cycle: A START condition is established by the Master Device followed by a call to the slave address [0110000] with the eighth bit held low to indicate a WRITE request.

**2<sup>nd</sup> cycle**: After an acknowledge signal is received by the master device (The MEMSIC device pulls the SDA line low during the 9<sup>th</sup> SCL pulse), the master device sends [00100001] as the target address (Internal Control Register 0). The MEMSIC device should acknowledge receipt of the address (9<sup>th</sup> SCL pulse).

**3<sup>rd</sup> cycle**: The Master device writes to the MEMSIC device's Internal Control 0 register the code [11100001] (PASSWORD bit) to initiate a SET action. The MEMSIC device should send an Acknowledge.

#### **EXAMPLE OF FIFO ENABLE**

1st cycle: A START condition is established by the Master Device followed by a call to the slave address [0110000] with the eighth bit held low to indicate a WRITE request.

**2<sup>nd</sup> cycle**: After an acknowledge signal is received by the master device (The MEMSIC device pulls the SDA line low during the 9<sup>th</sup> SCL pulse), the master device sends [00001110] as the target address (Internal Control Register 0). The MEMSIC device should acknowledge receipt of the address (9<sup>th</sup> SCL pulse).

**3<sup>rd</sup> cycle**: The Master device writes to the MEMSIC device's Internal Control 0 register the code [00000001] (PASSWORD bit) to initiate a SET action. The MEMSIC device should send an Acknowledge.


### **EXAMPLE OF FIFO ENABLE AND ADDRESS LOOPBACK ENABLE**

1st cycle: A START condition is established by the Master Device followed by a call to the slave address [0110000] with the eighth bit held low to indicate a WRITE request.

**2<sup>nd</sup> cycle**: After an acknowledge signal is received by the master device (The MEMSIC device pulls the SDA line low during the 9<sup>th</sup> SCL pulse), the master device sends [00001110] as the target address (Internal Control Register 0). The MEMSIC device should acknowledge receipt of the address (9<sup>th</sup> SCL pulse).

**3<sup>rd</sup> cycle**: The Master device writes to the MEMSIC device's Internal Control 0 register the code [10000001] (PASSWORD bit) to initiate a SET action. The MEMSIC device should send an Acknowledge.

# **OPERATING TIMING**



SET/RESET

Take Measurement

⟨ □ ⟩ Read data

Repeat T & R


Wait the device to be ready for next operation

# **Operating Timing Diagram**

Parameter	Symbol	Min.	Max.	Unit
Time to operate device after V <sub>DD</sub> valid	top	5		ms
Minimum time interval between SET or RESET to other operations	tsR	1		ms
	t™ BW=00	6.6		ms
	t <sub>TM</sub> BW=01	3.5		ms
	t™ BW=10	2.0		ms
	t™ BW=11	1.2		ms

### **SOLDERING RECOMMENDATIONS**

MEMSIC magnetic sensor is capable of withstanding an MSL1 / 260 °C solder reflow. Following is the reflow profile:




### Note:


- The second reflow cycle should be applied after device has cooled down to 25 °C (room temperature)
- This is the reflow profile for Pb free process
- The peak temperature on the sensor surface should be limited under 260 °C for 10 seconds.
- Solder paste's reflow recommendation should be followed to get the best SMT quality.

If the part is mounted manually, please ensure the temperature could not exceed 260 ℃ for 10 seconds.

# **PACKAGE DRAWING (WLP package)**




# **RECOMMENDED LAND PATTERN DESIGN**



### RELATIONSHIP BETWEEN THE MAGNETIC FIELD AND OUTPUT CODE

The measurement data increases as the magnetic flux density increases in the arrow directions.



MEMSIC MMC5617WA Y Page 20 of 21 01/2024

# **Revision History**

Date	Revision	Description
2024-01-01	version 1.0	Formal version 1 <sup>st</sup> release
2024-01-29	version 1.1	Some update based on 3lots characterization result